

HOW DO YOU PLUMB A SURGE TANK?

RACEWORKS™
PASSION FOR PERFORMANCE

Overflow and Pressure Regulator Return Line are interchangeable.
Some believe that minimising restriction on the return line is best.
Either setup will work well. PAT's preference is as pictured.



HOW DO YOU PLUMB A CATCH CAN?

RACEWORKS™
PASSION FOR PERFORMANCE

AN-12 Breather/s.

Can be replaced with an AN-12 hose and plumbed back to intake for sealed system applications.

Inlets.

Hoses run to
Rocker Cover Breather Port/s.

AN-10 Drain Tap.

Can be replaced with an
AN-10 hose drained to
sump if required.

