


# MOTORSPORT MAP SENSOR 5 BAR MAP-501



Raceworks recommended these sensors are not be mounted directly into the fuel rail or engine block; rather are remotely mounted and connected via a flexible hose. If required, use Pressure Sensor Extension Hose RWM-005.


## CALIBRATION

0kpa = 0.5v  
500kpa = 4.5v



## SPECIFICATIONS


- Premium Compact Sensor with Stainless Steel Body
- 0-5 Volt, 1/8" NPT, Inc Plug & Pins




Looking into the back of the connector or sensor

## WIRING DETAILS

PIN	Description
1	Sensor Ground
2	Signal
3	+5V



## CONNECTOR KIT



Use tool RWT-005 to crimp the pins.

